



FERRITE CORES · POWDER CORES · AMORPHOUS & NANOCRYSTALLINE CORES BOBBINS & MOUNTING HARDWARE · THERMISTORS, FILTERS & CHOKES



FERRITE CORES

Manufacturers Represented:

- Fair-Rite National
- Magnetics
 - Magnetics
- Group Description:

Ferrites are ceramic, homogeneous materials composed of various oxides with iron oxide as their main constituent. Depending on the application, there are two types of ferrite core material.

• EPCOS

TDK

Manganese-Zinc ferrite (MnZn) is used in applications requiring higher permeability and saturation levels, generally for high frequency transformer applications - important characteristics being high flux density and/or low core losses.

Nickel-Zinc ferrite (NiZn) is used in applications needing higher resistivity and is more suitable for frequencies above 1 MHz. Applications are EMC, filtering, power, wireless transfer of power, etc. Cores can also be classified by shape: Toroidal cores, U core, E cores, I cores, Pot cores, cylindrical cores, etc. Core geometries can be modified by machining to meet specific magnetic and mechanical requirements. Core gapping, Toroidal slotting and custom machining available.

AmoFlux[®]

Ferroxcube

POWDER CORES

- Group Sub-categories:
- MPP
- Kool Mu[®]
- XFlux[®]

High Flux

Manufacturers Represented:

- Magnetics, Inc.
- **Group Description**

Powder Core products are distributed air gap cores primarily used in power inductor applications, specifically switched-mode power supply (SMPS) output filters (DC inductors). Other power applications include differential inductors, boost inductors, buck inductors and flyback transformers. Power Core material characteristics are high resistivity, low

hysteresis and eddy current losses and excellent inductance stability under both DC and AC conditions. Powder Core materials are not pressed with an organic binder so there is no thermal aging.

AMORPHOUS & NANOCRYSTALLINE CORES –

Group Sub-categories:

- Iron-based
- Manufacturers Represented:
- Toshiba:
- AMOBEADS®

Cobalt-based

- SPIKE KILLER[®]
- **Group Description**

Amorphous metals are produced by using a rapid solidification technology where molten metal is cast into thin solid ribbons by cooling at a rate of one million degrees C/sec. Amorphous magnetic metal has

high permeability due to no crystalline magnetic anisotropy allowing smaller, lighter and more energy efficient designs in many high frequency applications for inverters, adjustable speed drives and power supplies. Due to the material having no crystalline magnetic anisotropy, amorphous magnetic metal has high permeability which makes it an ideal option for applications in the alternative energy sector. Amorphous iron (Metglas®) and nanocrystalline (FINEMET®) work well in mag amp and high efficient power applications while amorphous cobalt (Toshiba) works well in suppression devices.

EPCOS

BOBBINS & ACCESSORIES

- Group Sub-categories:
- Ferrite Bobbins
- Surface Mount
- Through Hole
- Manufacturers Represented:
- Miles-Platts Ferroxcube
- **Group Description**

Bobbins, also known as coil formers, are used for efficient winding and termination of magnetic components. Dexter provides precision plastic injection moldings for use in electrical, automotive and medical sectors.

In addition to standard bobbin offerings, Dexter is able to configure customizations, including pin modifications, higher and lower profilesand custom stack heights. More than half of Dexter products are custom designs specific to application requirements. Dexter also supplies mounting clamps (clips), toroid mounts and toroid headers.



Lamination Bobbins

Toroid Mounts

· Solenoids

Magnetics













www.dextermag.com



ELECTRONICS

Group Sub-categories:

- Thermistors · Beads-on-leads
- Capacitors

Manufacturers Represented:

- Ferronics • EPCOS • TDK
- Fair-Rite
- Group Description

- Chokes/Filters
- Ametherm
 - RTI Electronics

As a prime supplier for cores into the power supply industry, Dexter has expanded to include electronics such as thermistors, capacitors, beads, chokes, resistors and filters for varying power supply applications. We can assist in choosing the correct component for your application.









SOLUTIONS TO FIT YOUR DESIGN NEEDS

- Engineering & Design Assistance •
- Inductance Testing •
- Special Packaging •
- Bag and Tag
- Bar Coding
- Custom Fabrication .
- System Assembly •
- Inventory Management •
- Material Warehousing •
- Coating .
- ISO9001 / AS9100

On-site Class 10000 Clean Room

Stocked Parts for Immediate Delivery -



Core Gapping and Toroid Slotting







Dexter Magnetic Technologies was founded as Permag Corporation in 1951 as the FIRST global magnetic materials distributor.

Since then, Dexter Magnetic Technologies has become your essential magnetic partner. The company's growing supply chain offers the most diverse offerings of current magnetic materials. Our experienced engineers and support staff can help you choose the correct "off-the-shelf" components or assist in a custom, cost effective solution to your needs.

Dexter continues to invest in a strong future, with AS9100 certified facilities and ISO7 Clean Room capabilities.

magnetic solutions: realized and optimized

Dexter Magnetic Technologies, Inc. 1050 Morse Avenue Elk Grove Village, Illinois 60007-5110

info@dextermag.com

www.dextermag.com

847 956 1140 PHONE 800 317 2537 TOLL FREE



YOUR DEXTER DIRECT CONTACTS

John Lawlor - Product Manager jlawlor@dextermag.com 847 952 5572 DIRECT Charles Wild - Business Manager cwild@dextermag.com 716 864 1993 DIRECT

Diane Brickley - Sales Representative dbrickley@dextermag.com 847 952 5595 DIRECT April L. Clarke - Sales Representative aclarke@dextermag.com 847 952 5590 DIRECT Kathy Hilbert - Sales Representative khilbert@dextermag.com 978 937 1500 DIRECT

